

**How can I test the alphanumeric value of a parameter?**

Use the instruction STR like:

Dyelot\_Paramstr(â€™BAT-TEMPâ€™)=â€™Highâ€™

Important : add â€™strâ€™ to the parameter without any space

*Author: Datacolor*

*Saved From: <http://knowledgebase.datacolor.com/article-92.html>*