

How do I insert a sample manually?(L*,a*,b* coordinates or Reflectance values)

Click on the small arrow that is located on the right of the measurement icon. Then select **Lab** or **%R 31 pts** input method, this will change the button label. Click on that button and insert the values you want.

Author: Datacolor

Saved From: <http://knowledgebase.datacolor.com/article-452.html>