

Exception EDBE Engine Error Invalid string or buffer length. You use a Sybase engine (not Sybase Server/Client) and no user is defined in BDE Administrator

Open BDE Administrator
Click the name DCI_ITM
Fill the USER NAME field with DCI
Save modification on exit !

Author: Datacolor

Saved From: <http://knowledgebase.datacolor.com/article-98.html>