

Labels do not print correctly, printer does not feed labels correctly, the ready light on the printer blinks after attempting to print.

This usually indicates that the printer is malfunctioning. Print a windows test page from printer properties in Control Panel. If the printer behaves in the same fashion, call Dymo @ 203-588-2500.

Author: Datacolor

Saved From: <http://knowledgebase.datacolor.com/article-141.html>