

How do I change the standard measurement of my instrument's diagnostic tile?

If you have changed the calibrating white tile for your instrument, you will need to delete the standard measurement of your diagnostics tile. To do so, select Instrument menu, Instrument Setup, General Options tab. Then select Green Tile Test folder on left, and click on button, *All Diagnostics Standards*.

Author: Datacolor

Saved From: <http://knowledgebase.datacolor.com/article-160.html>