

How do I display the Gray Scale for Staining and Gray Scale for Color Change in Datacolor Tools?

In Tools go to the tab marked "Forms" then select the button "Screen forms". Click on the magnifying glass at the upper right and type in "Gray" and the forms "Gray Scale for Color Change" and "Gray Scale for staining" will appear. Select the appropriate form and click ok to display the values.

Author: Datacolor

Saved From: <http://knowledgebase.datacolor.com/article-638.html>