

SmartWeigh does not display the same number of decimals than ITMProcess. Why?

SmartWeigh can use a different unit than ITMProcess. To check the unit, start SmartWeigh setup and open the *General* window

Author: Datacolor

Saved From: <http://knowledgebase.datacolor.com/article-93.html>