

**I have a problem with instrument calibration or communication, or I get the following error
"component error return the following transfer error will now abort media name data component df**

Exit all applications

Delete the file c:Paintmkrspectro.Â (this is a file named "spectro", not a folder named spectro.)

Restart windows.

Install instrument drivers by inserting the Paintmaker installation CD.

When prompted, select "CHANGE ACTIVE INSTRUMENT" and install the correct instrument and calibration data.

Author:

Saved From: <http://knowledgebase.datacolor.com/article-2.html>