

The settings specified in the hrbcomm.ini were not valid.

This error has been noted to occur on Windows 2000 systems and will most likely occur on other O/S beyond Win 98 as well when communicating via a computer to computer connection to a Fluid Management (Colorpo) dispenser.

It happens because of the following line in the Harbilcomm.ini file located in the C:Paintmkrdispense subdirectory: Settings = 9600,N,8,1 ;The Â baud rate, parity, data bits, and stop bits respectively. The fix is to remove the semi-colon and the entire description to the right of the semi-colon so that the line reads like this: Settings = 9600,N,8,1

Author:

Saved From: <http://knowledgebase.datacolor.com/article-5.html>